



Market Central[®]

www.secureswitch.com

500 Business Center Drive Pittsburgh, PA 15205 USA
412.494.2800 **CAGE 1BGJ7**

SwitchMaster[®] R5000 Series
Ultra-Compact Ganged A/B Switching System

AUGUST 2015

| | |
|--|---------|
| 2U HIGH, 19" RACK MOUNT CHASSIS | 5000722 |
| CONTROLLER CARD – BASIC RS232/MANUAL (FRONT & REAR CARD SET) | 5000764 |
| CONTROLLER CARD – SNMP/ ETHERNET SUPPORT (FRONT & REAR CARD SET) | 5000765 |
| CONTROLLER CARD – SNMP EXPANSION (FRONT & REAR CARD SET) | 5000790 |
| EXTERNAL P/S ADAPTER CARD (SINGLE SLOT) | 5000752 |
| DC POWER SUPPLY CARDS (-48 VOLT) (FRONT & REAR SET) | 5000767 |
| SINGLE DC OUTPUT POWER SUPPLY CARD | 5000754 |
| POWER SUPPLY CARD (INCLUDES 2 EXTERNAL AC/DC POWER MODULES 5000761) | 5100740 |
| EXTERNAL AC/DC POWER SUPPLY MODULE | 6000761 |
| AC POWER SUPPLY CARD - REQUIRES TWO SLOTS (FRONT & REAR CARD SET) | 5000763 |
| RJ45 A/B SWITCH CARD, LATCHING - SUPPORTS UP TO 1 GbE | 5000725 |
| RJ45 (10 PIN) A/B SWITCH CARD, LATCHING - SUPPORTS UP TO 1 GbE | 5000807 |
| CAT6 RJ45 A/B SWITCH CARD, LATCHING - SUPPORTS UP TO 10 GbE | 5000782 |
| CAT6 RJ45 A/B SWITCH CARD, NON-LATCHING - SUPPORTS UP TO 10 GbE | 5000786 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, LATCHING | 5000737 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, LATCHING | 5000772 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, PSEUDO NON-LATCHING | 5000735 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, PSEUDO NON-LATCHING | 5000726 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, NON-LATCHING | 5000803 |
| MULTIMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, NON-LATCHING | 5000804 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, LATCHING | 5000872 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, LATCHING | 5000873 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, PSEUDO NON-LATCHING | 5000874 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, PSEUDO NON-LATCHING | 5000875 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, ST CONNECTORS, NON-LATCHING | 5000808 |
| SINGLEMODE FIBER OPTIC A/B SWITCH CARD, SC CONNECTORS, NON-LATCHING | 5000882 |
| DB9 A/B SWITCH CARD, LATCHING | 5000736 |
| DB15 A/B SWITCH CARD, LATCHING | 5000729 |
| DB25 A/B SWITCH CARD, LATCHING | 5000730 |
| 75 OHM VIDEO F-TYPE A/B SWITCH CARD, LATCHING | 5000795 |
| 75 OHM VIDEO F-TYPE A/B SWITCH CARD, NON-LATCHING | 5000796 |
| RS232/DB25 SIGNAL MONITORING A/B SWITCH CARD, LATCHING | 5000856 |
| RS530/DB25 SIGNAL MONITORING A/B SWITCH CARD, LATCHING | 5000857 |
| BLANK FRONT/REAR PANEL (2 REQUIRED PER EMPTY SLOT) | 5000766 |

(lead-free versions of the above items are also available by changing the part # from 5xxxxxx to 6xxxxxx)
 Fiber Optic switches are also available with FC or LC connectors.



Market Central, Inc.

1. Specifications

Connectors:

RJ45 A/B SWITCH CARD – (3) RJ45 connectors (8 or 10 pin depending on model)
CAT6 RJ45 A/B SWITCH CARD – (3) CAT6 RJ45 connectors
FIBER OPTIC A/B SWITCH CARDS – (3) Duplex fiber optic SC or ST receptacles (FC and LC also available)
DB9 A/B SWITCH CARD – (3) DB9 female connectors (male optional)
DB15 A/B SWITCH CARD – (3) DB15 female connectors (male optional)
DB25 A/B SWITCH CARD – (3) DB25 female connectors (male optional)
DB25 SIGNAL MONITORING A/B SWITCH CARD – DB25 female (port C), DB25 male (ports A & B)
F-TYPE A/B SWITCH CARD – (3) female F type connectors
CONTROLLER CARD – (1) RJ45, (2) RJ11
EXTERNAL POWER SUPPLY ADAPTER CARD – (2) two pin Molex connectors, (2) two position terminal block
INTERNAL AC POWER SUPPLY CARD – (1) IEC320 connector, (1) three position terminal block
INTERNAL DC POWER SUPPLY CARD – (2) three position terminal blocks

Indicators:

A/B SWITCH CARDS – (2) LED, one for A, one for B
CONTROLLER CARD – (2) LED, one for power, one for status
EXTERNAL POWER SUPPLY ADAPTER CARD – (2) LED, one power indicator for each external power supply
INTERNAL AC or DC POWER SUPPLY CARD – (1) LED, power indicator
DB25 SIGNAL MONITORING A/B SWITCH CARD – (6) LEDs, A, B, TxD, RxD, RTS, DCD

Switches:

A/B SWITCH CARDS – (1) momentary toggle switch, (1) 8-position dip-switch
CONTROLLER CARD – (1) momentary toggle switch, (1) 8-position dipswitch, (1) momentary push-button switch, and (1) key-lock switch.
DB25 SIGNAL MONITORING A/B SWITCH CARD – (1) momentary toggle switch, (2) 8-position dip-switch

Ethernet Management Interface (SNMP/Ethernet Controller Card only):

10Base-T, Half-Duplex, does not support Auto MDI-X

Power:

RJ45 A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 92 mA max while switching.
CAT6 RJ45 A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 92 mA max while switching.
FIBER OPTIC A/B SWITCH CARD, PSEUDO NON-LATCHING – 12 VDC, 40 mA in A position, 120 mA max in B position, additional 13 mA max while switching.
FIBER OPTIC A/B SWITCH CARD, NON-LATCHING – 12 VDC, 40 mA in A position, 133 mA max in B position.
FIBER OPTIC A/B SWITCH CARD, LATCHING – 12 VDC, 40 mA normal, additional 80 mA max while switching.
DB9 A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 92 mA max while switching.
DB15 A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 147 mA max while switching.
DB25 A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 239 mA max while switching.
RS232/DB25 SIGNAL MONITORING A/B SWITCH CARD – 12 VDC, 40 mA normal, additional 239 mA max while switching
RS530/DB25 SIGNAL MONITORING A/B SWITCH CARD – 12 VDC, 100 mA normal, additional 239 mA max while switching
F-Type A/B SWITCH CARD, LATCHING – 12VDC, 40 mA normal, additional 52 mA max while switching.
F-Type A/B SWITCH CARD, NON-LATCHING – 12VDC, 40 mA in A position, 92 mA max in B position.
CONTROLLER CARD – 12 VDC, 100 mA normal, additional 250 mA with Ethernet module.
The rack may be powered with either a (90 – 264 VAC, 47 – 63 Hz) internal AC supply card, or a (36 – 76 VDC) internal DC supply card, both of which provide 12 VDC, 4.2A max output. The rack may also be powered with one or two external (90 – 264 VAC, 47 – 63 Hz input, 12 VDC, 5A output) power supplies using the external power supply adapter card. Two or more power supplies may be used in a single rack for redundancy.

Market Central, Inc.

Rack Size:

RACK – 18 card slots, 3.5” H x 19” W x 12.5” D (including handles and connectors)
RJ45 A/B SWITCH CARD – one slot (0.937 inches wide)
CAT6 RJ45 A/B SWITCH CARD – one slot (0.937 inches wide)
FIBER OPTIC A/B SWITCH CARDS – one slot (0.937 inches wide)
DB9 A/B SWITCH CARD – two slots (1.875 inches wide)
DB15 A/B SWITCH CARD – three slots (2.812 inches wide)
DB25 A/B SWITCH CARD – three slots (2.812 inches wide)
DB25 SIGNAL MONITORING A/B SWITCH CARD – three slots (2.812 inches wide)
F-TYPE A/B SWITCH CARD – one slot (0.937 inches wide)
CONTROLLER CARD – one slot (0.937 inches wide)
EXTERNAL POWER SUPPLY ADAPTER CARD - one slot (0.937 inches wide)
INTERNAL AC or DC POWER SUPPLY CARD - two slots (1.875 inches wide)

Optical Wavelength: 800 through 1600 nm (latching multimode models)
850 and 1310 nm (non-latching multimode models)
1310 and 1550 nm (latching and non-latching single mode models)

Insertion Loss: 2.0 dB maximum (multimode models)
1.5 dB maximum (single mode models)

Optical Isolation: 45 dB minimum (latching multimode models)
35 dB minimum (non-latching multimode models)
55 dB minimum (latching and non-latching single mode models)

Environment:

TEMPERATURE 0° to 40° C operating, -10° to 70° C non-operating
HUMIDITY up to 80%, non-condensing
ALTITUDE 40,000 ft maximum

Market Central, Inc.

2. Introduction

The R5000 SwitchMaster[®] Switching System is a 2U 19" rack style chassis containing multiple A/B Switch Cards. Each switch card connects port A or port B to port C, through latching or non-latching telecommunication relays or fiber optic switch mechanisms. For models using latching mechanisms, the connection state will be maintained if power fails or is removed. Non-latching versions will revert to the port C to port A connection state when power is lost, and will remain in that state when power is restored until a new switch command is received. Pseudo Non-latching fiber optic switch cards fall back to the "Port C to Port A" connection when power fails or is removed. When power is re-applied, the optical switch in a pseudo non-latching fiber optic switch card will reconnect port C to the port (A or B) that was selected prior to the loss of power. The non-latching styles of fiber optic switch cards are often used when a fall-back or "failover" style of connection scheme is desired in the event of power failure.

The R5000 rack has 18 slots and can accept any mix of switch cards, power supply cards, and one Controller Card (one required per chassis). Any type of card can be installed in any slot in the R5000 rack, allowing for maximum flexibility of cable routing etc. If a single slot power supply card (such as the 5100740) is used, the rack can hold up to 16 A/B Switch Cards, and a Controller Card. Each A/B Switch Card can be individually switched, or the entire rack can be switched from the Controller Card. The Controller Card has a keyed switch to enable and disable manual switching (disables the front panel toggle switches on the Controller Card and on each switch card). The Controller Card has two RJ11 ports which provide for serial communications to the rack, and also allow multiple racks to be daisy-chained together to create a single system that can be controlled by the first rack in the daisy chain. The Controller Card also provides remote switching capabilities via an RS232 interface or using a +/- 12 VDC signal from a remote toggle switch.

The Controller Card consists of a front pc board assembly and a rear pc board assembly set, and is available in three different versions (RS232, SNMP/Ethernet, and SNMP Expansion). The RS232 version supports Rack and System Gang Switching using the manual toggle switches on the Controller Card and A/B Switch Cards, and supports RS232 communications on the gang-in and gang-out connectors. The RS232 Controller Card allows system level (all cards in all racks) switching with serial commands (see section 5.1 for additional info). The SNMP/Ethernet capable version features a RS232 terminal interface which can be used to control individual A/B switch cards, a rack of A/B switch cards, or system of daisy-chained racks, and to configure the Ethernet port parameters (see section 7 for additional info). The Ethernet port allows the rack or system of daisy-chained racks (containing the SNMP Expansion Controller Card) to be controlled using SNMP commands, Telnet commands, or via a built-in html based web browser interface. There can only be one SNMP/Ethernet capable Controller Card in a daisy-chained system of racks, and it must be in the first rack in the system. If daisy-chaining one or more racks from an SNMP/Ethernet capable rack, the additional racks must have an SNMP Expansion Controller Card, which is compatible with the message format from the SNMP/Ethernet Controller Card.

The SNMP/Ethernet Controller Cards also support SNMP traps or syslog messages (user configurable) for various events and errors, and can send these alerts to as many as 16 different remote monitoring locations.

The SNMP/Ethernet Controller Cards have an intelligent automatic switching capability. This feature allows the switching system to be used to monitor a specific Ethernet network connection and to automatically switch all ports (performs a system switch operation) based on whether the monitored IP address responds to ICMP echo requests (responds to PINGs) or not. See section 5.5 for additional details.

The DB25 Signal Monitoring switch cards are described in a separate manual.

3. Configuration

3.1 A/B Switch Card Configuration




Figure 3.1.1 – Typical A/B Switch Card Front & Rear Panels

Each A/B Switch Card has an 8-position DIP switch, used to set the card's address. Switch position 1 is the least significant bit, and position 8 is the most significant bit. Set each switch ON (as marked) for a '0', and OFF for a '1'. Card address 1 for example, would be DIP switch position 1 OFF, and positions 2-8 ON. Card addresses within a rack, or within a system of daisy-chained racks must be unique and one card **MUST** be addressed 1. Card address 0x00 is reserved and must not be used. A typical approach is to set rack 0x01, card addresses to 0x01 through 0x10 from left to right within the rack. In the second rack 0x02, set the card addresses to 0x11 through 0x20 and so on. The Controller Card communicates with the individual switch cards using a multi-drop scheme. If two A/B cards within the same rack or daisy-chained system of racks have the same address, both will try to respond at the same time, causing communication errors. Thus, the maximum number of A/B Switch Cards in a daisy-chained system of racks is limited to 255 switch cards.

3.2 Controller Card Rear PC Board Configuration




Figure 3.2.1 – Controller Card Rear Panel Outline

Market Central, Inc.

The Controller Card rear pc board assembly has two jumpers for shielding and grounding options. The two 3-position jumpers are positioned such that pin 1 is toward the card edge connector, and pin 3 is toward the RJ11 connectors. Each 3-position jumper has a 2-position shunt, used to connect two of the three positions together.

Table 3.2.1 – Controller Card Rear PC Board Jumper Settings

| Jumper | W1 | W2 |
|---|----------------------------------|----------------------------------|
| RJ45 Shield Connected to Frame Ground * Open | Pin 1 to Pin 2 Pin 2 to Pin 3 | |
| Power Supply Ground 100 Ohm Connection to Frame Ground * Direct Connection to Frame Ground | | Pin 1 to Pin 2 Pin 2 to Pin 3 |

* Factory Default Positions

Table 3.2.2 – RJ45 (Optional Ethernet Port) Pin Assignment

| Pin | Signal Name | Signal Direction |
|-----|---------------|------------------|
| 1 | Transmit Pair | Output |
| 2 | Transmit Pair | Output |
| 3 | Receive Pair | Input |
| 6 | Receive Pair | Input |

Table 3.2.3 – RJ11 GANG-IN Port Pin Assignment

| Pin | Signal Name | Signal Direction |
|-----|-------------------------------|------------------|
| 5 | Signal Ground | Not Applicable |
| 4 | Transmit Data / V+ | Output / Output |
| 3 | Receive Data / V- | Input / Output |
| 2 | System Control (OPEN,+12,-12) | Input and Output |

Note: The functions of pins 3 and 4, on the GANG-IN port, are set using jumpers on the front card. They can be configured as TXD and RXD for serial communication, or as V+ and V- to control the system control input with a remote toggle switch. The connections to V+ and V- are through 1 K ohm resistors. The System Control signal is used as an input and an output. As an Input signal it is normally open. This input is driven to +12 VDC to switch the system to A, and is driven to -12 VDC to switch the system to B. As an output, this signal is driven to +10 VDC when the user initiates a system switch to A, and is driven to -10 VDC when the user initiates a system switch to B.

Table 3.2.4 – RJ11 GANG-OUT Port Pin Assignment

| Pin | Signal Name | Signal Direction |
|-----|---------------|------------------|
| 5 | No Connection | Not Applicable |
| 4 | Transmit Data | Output |
| 3 | Receive Data | Input |
| 2 | Signal Ground | Not Applicable |

Note: A standard RJ11 male/male crossover cable is required to connect from the gang-out port on one rack to the gang-in port on the next.

Market Central, Inc.

3.3 Controller Card Front PC Board Configuration

The Controller Card front pc board has an 8-position dipswitch and four jumpers for user configurable options. The four 3-position jumpers are positioned such that pin 1 is toward the front panel, and pin 3 is toward the rear of the card. Each 3-position jumper has a 2-position shunt, used to connect two of the three positions together.

Table 3.3.1 – Controller Card Front PC Board Jumper W1 and W2 Settings

| Jumper | W1 | W2 |
|--|----------------------------------|----------------------------------|
| Gang-In Pin 3 Connected to TXD * Connected to V+ through 1K | Pin 1 to Pin 2 Pin 2 to Pin 3 | |
| Gang-In Pin 4 Connected to RXD * Connected to V- through 1K | | Pin 1 to Pin 2 Pin 2 to Pin 3 |

* Factory Default Setting

Jumpers W1 and W2 function as a pair to configure the gang-in port. Refer to table 3.2.3 for the GANG-IN port pin assignment. Connect to TXD and RXD to support RS-232 serial communications, or connect to V+ and V- through 1 K ohm resistors to control the system control input with a remote toggle switch. Note that the serial port is required for setup of the network parameters.

Table 3.3.2 – Controller Card Front PC Board Jumper W4 and W5 Settings

| Jumper | W4 | W5 |
|---|----------------------------------|----------------------------------|
| Input Port Source Normal RS-232 * Optional SNMP/Ethernet version ~ | Pin 1 to Pin 2 Pin 2 to Pin 3 | |
| Input Port Source Normal RS-232 * Optional SNMP/Ethernet version ~ | | Pin 1 to Pin 2 Pin 2 to Pin 3 |

* Factory Default Setting – RS232 and SNMP Expansion versions

~ Factory Default Setting – SNMP/Ethernet version

Jumpers W4 and W5 function as a pair to configure the input port source. It should not be necessary to change these jumpers from their factory set positions. These jumpers configure the source for communications to the internal processor on the Controller Card. If you have a Controller Card with an optional SNMP/Ethernet module installed, both jumpers should be set to connect pins 2 and 3. Otherwise both jumpers should be set to connect pins 1 and 2 to allow the processor to communicate with the RS-232 signals from the GANG-IN port.

Market Central, Inc.

The 8-position dipswitch has a different function depending on the type of Controller Card. Refer to Table 3.3.3 for the RS232 version only. The SNMP/Ethernet and SNMP Expansion versions use this dip switch to set the rack address.

Table 3.3.3 – Controller Card Dip Switch Settings (RS232 Version Only)

| Switch | SW2-1 | SW2-2 | SW2-3 | SW2-4 | SW2-5 | SW2-6 |
|------------------------|-------|-------|-------|-------|-------|-------|
| Security Character | | | | | | |
| 0 | 0N | ON | ON | ON | | |
| 1 | OFF | ON | ON | ON | | |
| 2 | ON | OFF | ON | ON | | |
| 3 | OFF | OFF | ON | ON | | |
| 4 | ON | ON | OFF | ON | | |
| 5 | OFF | ON | OFF | ON | | |
| 6 | ON | OFF | OFF | ON | | |
| 7 | OFF | OFF | OFF | ON | | |
| 8 | ON | ON | ON | OFF | | |
| 9 | OFF | ON | ON | OFF | | |
| : | ON | OFF | ON | OFF | | |
| ; | OFF | OFF | ON | OFF | | |
| < | ON | ON | OFF | OFF | | |
| = | OFF | ON | OFF | OFF | | |
| > | ON | OFF | OFF | OFF | | |
| ? | OFF * | OFF * | OFF * | OFF * | | |
| Security Code Enabled | | | | | ON | |
| Security Code Disabled | | | | | OFF * | |
| Safe Mode Enabled | | | | | | ON |
| Safe Mode Disabled | | | | | | OFF * |

* Factory Default Setting

When the security code is enabled (SW2-5 set to ON), the selected security character must precede any serial commands received at the gang in port of the first rack in the system. The security code must be disabled on all following racks. Refer to section 5.1 for a list of applicable serial commands.

Safe mode operation (SW2-6 set to ON) prevents switching commands from the gang-in port, allowing only status request commands. This provides a level of protection against corrupt or spurious data causing unintended switching in an application where only status is required of the gang-in port. Set safe mode OFF to allow A/B switching from the gang-in serial port. Safe mode must be disabled (OFF) on racks connected to the gang-out port of another R5000 rack, to allow system switching to occur (otherwise system switching will be blocked from higher level racks).

Dip switch positions 7 and 8 are reserved for future development, and should be left in the OFF position.

For the SNMP/Ethernet and SNMP Expansion Controller Cards, the 8-position dipswitch SW2 is used to define the Controller Card (or rack) address. Rack addresses within the system must be unique, but may be repeated in other systems. The rack address space and card address space are separate, i.e. racks and cards can have the same address. It is necessary that address “00” be left unused, and recommended that the racks be assigned addresses “01” through “FF”. The network Controller Card communicates with other Controller Cards using a multi-drop scheme. If two racks within the same system have the same address, both will try to respond at the same time, causing communication errors. Switch position 1 is the least significant bit, and position 8 is the most significant bit. Set each switch ON (as marked) for a '0', and OFF for a '1'. Address 1 for example would be position 1 OFF, and positions 2-8 ON.

Market Central, Inc.

4. Installation

The A/B Switch Cards consist of a single card, which is inserted from the rear of the rack. The Controller Card consists of a front card and a rear card.

4.1 Controller Card Rear PC Board Installation

- 4.1.1 Using the card guides, carefully slide the rear card into the rack, until it makes connection to the 8-position socket on the rack backplane.
- 4.1.2 Secure the rear card to the rack at the top and bottom of the card, using the screws provided.
- 4.1.3 Using standard RJ11 male/male crossover cable, connect the gang out from one rack to the gang in connector on the next if multiple racks are to be daisy-chained together. Repeat this step until all racks have been connected.

4.2 Controller Card Front PC Board Installation

- 4.2.1 Using the card guides, carefully slide the front card into the rack, until it makes connection to the 36-position card edge connector on the rear card.
- 4.2.2 Secure the front card to the rack at the top and bottom of the card, using the screws provided.

4.3 A/B Switch Card Installation

- 4.3.1 From the rear of the rack, using the card guides, carefully slide the card into the rack, until it makes connection to the 8-position socket on the rack backplane.
- 4.3.2 Secure the rear card to the rack at the top and bottom of the card, using the screws provided.
- 4.3.3 If not already in place, secure the front panel to the rack, using the screws provided.

5. Operation

When power is applied to the Controller Card, the PWR LED should illuminate.

When power is applied to the A/B Switch Card, either the "A" LED or the "B" LED should illuminate to indicate the currently connected port.

When the Key-Lock switch on the Controller Card is OFF, the manual toggle switches on the Controller Card and all the A/B Switch Cards in the rack will be disabled. Note that the rack may still switch in response to a command received on the RS232 Gang-In port, or the Ethernet port.

When the Key-Lock switch on the Controller Card is ON, the manual toggle switches in the rack function normally. The toggle switches on the A/B Switch Cards are used to switch only that card. Hold the switch in the "A" position to connect Port A to Port C. The "A" LED will illuminate when the switch operation has been completed. Release the switch when switching has finished. Hold the switch in the "B" position to connect Port B to Port C. The "B" LED will illuminate when the switch operation has been completed. Release the switch when switching has finished.

The toggle switch on the Controller Card is used to switch all cards in the rack, and is operated in the same fashion as the individual toggle switches on the A/B Switch Cards. To switch an entire system of daisy-chained racks, hold the "system" push-button while operating the toggle switch on the Controller Card.

The Controller Card STAT LED should blink under the following conditions:

The front panel control switches are used to initiate a "rack" or "system" level switching operation.
The Controller Card received a switch command on the RS232 Gang-In port or the Ethernet port.

Market Central, Inc.

5.1 RS-232 Serial Switching

The RS232 version of the Controller Card allows the user to remotely switch all of the cards in a rack or system of daisy-chained racks using the serial commands listed in Table 5.1.1 below. The SNMP/Ethernet version of the Controller Card does not support the one character serial commands listed in Table 5.1.1 below, but instead uses the enhanced console commands listed in Section 7 of this manual. Also note that the data rate of the Gang-In port increases to 9600 bps for the SNMP/Ethernet version of Controller Card. The SNMP Expansion Controller Card does not support the one character serial commands listed in Table 5.1.1 below, but will pass these commands through to the cards in the rack and to subsequent racks in the system.

Table 5.1.1 – RS-232 System Switching Commands (RS232 version of Controller Card)

| Command | Description |
|---------|----------------------|
| A <CR> | Switch “system” to A |
| B <CR> | Switch “system” to B |
| S <CR> | Request “status” |

Notes:

1. The RS232 terminal device connected to the RS232 version of Controller Card’s Gang-In port must be set to 2400 Baud, No Parity, 8 Data Bits, 1 Stop Bit. Connect using the supplied DB9 to RJ11 adapter and RJ11 to RJ11 crossover cable.
2. The one character commands above are CASE SENSITIVE, and must be followed by a carriage return. Refer to table 3.3.3 for a list of optional “security” characters which may precede these commands.
3. Note: These RS232 commands only allow control of the entire system, thus the status of all cards in the system should be the same. Therefore, only one card (address 0x01) in the first rack will respond to the “S” status command. If there is no card with address 0x01 in the first rack, there will be no response to the status command.

5.2 “SYSTEM” Switching Using the Gang-In System Control Signal

The System Control signal is used as an input and an output. As an Input signal it is normally open. This input is driven to +12 VDC to switch the system to A, and is driven to –12 VDC to switch the system to B. The input circuit requires approximately 1 mA to operate properly.

As an output, this signal is driven to +10 VDC when the user initiates a system switch to A, and is driven to –10 VDC when the user initiates a system switch to B. To protect the output circuits, the output goes through a 1 K ohm resistor. Therefore, this output should not be used to drive a large load.

The gang-in connector normally accepts RS-232 input signals, but can be configured to supply +12 VDC and –12 VDC. Refer to table 3.3.1 for jumper configuration information. These +12 VDC and –12 VDC outputs are provided through 1 K ohm resistors, and therefore should not be used to drive large loads. These outputs are provided to allow system switching, using only a remote contact. It is recommended that a momentary toggle switch be used.




Figure 5.2.1 System Switching, Using a Remote Momentary Toggle Switch

Market Central, Inc.

5.3 RS232 Console Commands (for SNMP/Ethernet Controller Card)

This section is applicable to SNMP/Ethernet Controller Cards. The GANG-IN RS232 interface on the SNMP/Ethernet Controller Card operates at 9600. The GANG OUT interface operates at 2400 bps. This allows the GANG OUT interface to connect to the GANG IN port on another R5000 (that does not have the Ethernet Module installed) so that multiple racks can be daisy-chain connected together. When daisy chaining multiple racks, only the first rack in the chain may have an Ethernet Module installed.

SNMP/Ethernet Controller Cards support an enhanced set of serial commands that are listed below and described in more detail in section 7. To communicate with the internal Ethernet module, set your RS232 terminal to 9600 baud, no parity, 8 data bits, and 1 stop bit. Connect this terminal to the GANG-IN RS232 interface on the SNMP/Ethernet Controller Card using the DB9 to RJ11 adapter and RJ11 crossover cable provided with the SNMP/Ethernet Controller Card.

When you apply power to the system, the Ethernet module runs a series of internal self tests and configuration steps. This takes approximately 5 seconds. After this process is complete you will see a sign-on message displayed on your serial console, similar to the following:

```
Network Agent Version 2.9T APR 2014
Copyright (c) 2014
All rights reserved
System starting ...
Console ready

>
```

At this point the Ethernet module is now ready to receive RS232 serial commands via the GANG IN connector. If you type “help” followed by the ENTER KEY, the list of available commands will be displayed as shown below. See Section 7 for a detailed description of each command.

CONSOLE COMMANDS:

```
GET          ALL (display all parameters)
GET          VERSION (display software versions)
GET[SET]    SYSTEM [A/B] (control all system ports)
GET[SET]    RACK N [A/B] (control single rack ports)
GET[SET]    PORT N [A/B] (control single port)
GET         POWER N (display power status)
GET[SET]    IPADDRESS [X.X.X.X]
GET[SET]    SUBNETMASK [X.X.X.X]
GET[SET]    GATEWAY [X.X.X.X]
GET[SET]    PINGREPLY [ON/OFF]
GET[SET]    SNMPENABLE [ON/OFF]
GET[SET]    READCOMMUNITYNAME [string]
GET[SET]    WRITECOMMUNITYNAME [string]
GET[SET]    WEBENABLE [ON/OFF]
GET[SET]    WEBPASSWORD [string]
GET[SET]    WEBTIMEOUT [N] (seconds)
GET[SET]    WEBPORT [N]
GET[SET]    TELNETENABLE [ON/OFF]
GET[SET]    TELNETPASSWORD [string]
GET[SET]    TELNETTIMEOUT [N] (seconds)
GET[SET]    TELNETPORT [N]
GET[SET]    MONITORIP [X.X.X.X] (0.0.0.0 to disable)
GET[SET]    MONITORMAC [X X X X X X] (X = HEX CHARS)
GET[SET]    MONITORINTERVAL [N] (1/10 seconds, 0 to disable)
GET[SET]    MONITORFAILCOUNT [N] (0 to disable)
GET[SET]    MONITOROKCOUNT [N] (0 = no auto recover)
GET[SET]    AUTHENTICATIONTRAP [ON/OFF]
GET[SET]    ALERTTYPE [TRAP/SYSLOG]
GET[SET]    ADMINIP N [X.X.X.X] (0.0.0.0 to disable an entry)
GET         ADMINIP (display all administrator IP addresses)
GET[SET]    MANAGER N [X.X.X.X] (0.0.0.0 to disable an entry)
GET         MANAGER (display all SNMP managers)
PING        X.X.X.X (ICMP ECHO to remote host)
SAVE        save settings for next startup
RESET       restart (use after SAVE)
SET         DEFAULTS (restore default user settings, save required)
```

Market Central, Inc.

5.4 Remote Ethernet Management (for SNMP/Ethernet Controller Card)

In order to use the Ethernet network port you must set the IPADDRESS, SUBNETMASK and GATEWAY address of the internal Ethernet module before connecting to your network. See section 6 for more details.

The internal Ethernet module allows remote management of the switching system via SNMP, Telnet, or web browser. The SNMP interface allows access to the MIB variables described in section 9. SNMP is also used by SwitchCenter the java based graphical user interface application provided with the SNMP/Ethernet Controller Card. The Telnet and web browser interfaces provide access to the console commands described in section 7. Each of these remote management interfaces may be enabled or disabled.

The SAVE command is used to cause the internal Ethernet module to store the configuration parameters in non-volatile memory. If the Ethernet module is reset prior to performing a SAVE command, configuration changes will be lost.

5.5 Automatic Switching (for SNMP/Ethernet Controller Card)

The SNMP/Ethernet Controller Card can be configured to automatically switch between a “normal” connection state (all COMMON ports are connected to their respective B ports) and a “bypass” or “failover” connection state (all COMMON ports are connected to their respective A ports). User configurable failover and recovery parameters control the auto-switching functions to allow the switch to be used in a variety of applications.

In order to be able to perform the auto bypass and auto recovery switching functions, the internal Ethernet module issues ICMP echo request (PING) packets in order to determine if a path exists to an IP address specified during configuration of the automatic switching feature. If the “normal” network path connections between the Ethernet module and the device being monitored go down for any reason, the Ethernet module will no longer be able to PING the specified IP address, and will then automatically switch from the “normal” connection state (all COMMON ports connected to their respective B ports) to the “bypass” or “failover” connection state (all COMMON ports are connected to their respective A ports) by internally executing a “SET SYSTEM A” command. Once the problems on the primary path have been corrected, the user can issue a “SET SYSTEM B” command to cause the switching system to switch from the failover connection state back to the normal connection state. Or if auto recovery is enabled, the switching will automatically re-connect the normal path connections (by internally executing a “SET SYSTEM B” command) when it is again able to PING the user specified IP address. When using the auto recovery feature, it is important that the Ethernet network port on the SNMP/Ethernet Controller Card be connected to the user’s network such that the normal path is continuously being monitored even when the backup path has been selected, otherwise the switching system could repeatedly switch (flap) back and forth between the failed primary path & the functioning backup path. See the following diagrams for examples of auto switching configurations.

When the auto switching feature is enabled, manual and remote switching can still be performed using the front panel toggle switch or by issuing serial or Ethernet commands, but this can affect the operation of the automatic switching feature. This is because the automatic switching feature is only aware of “system level” commands, i.e. “SET SYSTEM A”, “SET SYSTEM B”, and manual switching using the front panel toggle switch while holding in the “SYSTEM” pushbutton switch. If the user initiates any of these “system level” commands, the switching system will execute the command and the automatic switching feature will record the new connection state. The automatic switching feature will then continue to monitor the connection path to the selected IP address and if it reaches the “monitorokcount” or the “monitorfailcount” thresholds, it will automatically switch connections as it normally would.

However, if the switching system receives a “SET RACK” command, or if the rack is switched using the front panel toggle switch without holding in the “SYSTEM” pushbutton switch, these commands will not be recorded by the automatic switching feature - it will be unaware that the switching system has changed connection states. Under certain conditions when in this state, the automatic switching feature will not automatically switch connection states if it reaches the “monitorokcount” or “monitorfailcount” thresholds because it “thinks” that it is already in the correct connection state. To recover from this condition the user can either power cycle the SNMP/Ethernet Controller Card, issue a “RESET” command, or execute a “system level” command. Any of these actions will cause the automatic switching feature to record the current connection state of the switch, which then allows it to again operate normally.


Connection changes made using the “SET PORT” command also are not recorded by the automatic switching

Market Central, Inc.

feature. Thus under certain conditions, the automatic switching feature will not automatically switch connection states as described above when “rack level” commands are issued.


Auto Failover & Manual Recovery

Note: The R5000 monitors the WAN connections by PINGing the far side router thru the primary WAN link. If the primary WAN link fails, the R5000 auto switches to the backup WAN link. Auto recovery is disabled in this configuration to prevent flapping.



Auto Failover & Auto Recovery

Note: The R5000 monitors the WAN connections by PINGing the far side router thru the primary WAN link. If the primary WAN link fails, the R5000 auto switches to the backup WAN link. When the primary WAN link is available again, the R5000 auto switches back to the primary WAN path.



The monitorip address and monitormac address parameters used by the automatic switching feature can be configured to allow the Ethernet module to monitor connectivity to any device within, or outside of the Ethernet module’s subnet. After you have entered the monitorip address, you can either manually enter the monitormac address, or allow the Ethernet module to determine it automatically.

If monitoring connectivity to a device on the same subnet as the internal Ethernet module, set the monitorip address and monitormac address parameters to the IP address and MAC address of the device being monitored. If monitoring connectivity to a device on a different subnet/network than the internal Ethernet module, set the monitormac address parameter to the MAC address of the gateway router on the Ethernet module’s subnet, and set the monitorip address parameter to the IP address of the device being monitored. This allows the PING packet issued by the Ethernet module to be routed through the gateway router to the target device on a different subnet/network. If you don’t know the MAC address of the target device or of the gateway router, one method is to open a command prompt window on a P.C. attached to that same subnet and use the “arp -a” command to retrieve this information from the P.C.’s arp cache (you may need to PING the IP address first before the entry will appear in the arp cache).

Market Central, Inc.

Rather than manually configuring the monitormac address, you can also configure the Ethernet module to automatically determine the proper MAC address required for the PING packet. Enter the monitorip address information as noted above, and then set the monitormac address parameter to 00 00 00 00 00 00. This causes the Ethernet module to issuing an ARP request to the gateway router which will respond with the appropriate MAC address information needed.

6. Network Setup

To perform the initial setup of an SNMP/Ethernet version of Controller Card, you will need a serial terminal capable of 9600 baud, no parity, 8 data bits, and 1 stop bit. Connect this terminal to the GANG-IN port using the supplied DB9 to RJ11 adapter and RJ11 to RJ11 crossover cable.

Table 6.1 – DB9 to RJ11 Adapter Pin Assignment

| RJ11 PIN | SIGNAL | DIRECTION | DB9 |
|----------|------------------|---------------|-----|
| 3 | RECEIVED DATA | TO TERMINAL | 2 |
| 4 | TRANSMITTED DATA | FROM TERMINAL | 3 |
| 2 | GROUND | | 5 |

Apply power to the R5000 rack. The SNMP/Ethernet version of Controller Card requires about 5 seconds to boot up, while performing self tests and configuring.

After this process is complete you will see a sign-on message displayed on the serial console, i.e.

```
Network Agent Version 2.9T APR 2014
Copyright (c) 2014
All rights reserved
System starting ...
Console ready
>
```

At this point the Controller Card is ready for the low level configurations necessary before you will be able to communicate with the network port using TCP/IP. You will need to enter an IP address, subnet mask, and gateway address, as well as read and write SNMP community names if using SNMP, a telnet password for telnet access, or a web password for browser access. These parameters must be saved into non-volatile memory, and then the system must be reset to allow it to reconfigure with the new settings. Any time one or more of these parameters is changed, they must be saved followed by a system reset. The following shows a typical setup session. Change the entered parameters to suit your application requirements. All the console level commands available are described in detail in section 7.

```
>set ipaddress 192.168.1.200
IP Address: 192.168.1.200

>set subnetmask 255.255.255.0
Subnet Mask: 255.255.255.0

>set gateway 192.168.1.1
Gateway IP Address: 192.168.1.1

>set readcommunityname public
Read Community Name: public

>set writecommunityname private
Write Community Name: private

>save
saving...

>reset
resetting, please wait...
```

After the system reinitializes, you will again be greeted by the sign-on message as before. At this time you can attach

Market Central, Inc.

a 10base-T CAT5 cable between the Controller Card's Network port and an available port on your Ethernet hub or switch/router. The SNMP/Ethernet version of Controller Card will now respond to telnet, SNMP and/or HTTP messages at the assigned IP address depending on which options are enabled. Section 7 describes the commands that are available via the console prompt (telnet, web, or RS232 interface). Section 8 describes the operation of the web browser interface, and Section 9 provides a MIB Path Summary that lists the supported SNMP variables and their functions.

7. Console Commands (SNMP/Ethernet version of Controller Card)

When the R5000 powers up, it will send a sign-on message followed by a prompt character ">" to your serial terminal device, set at 9600 baud, no parity, 8 data bits, and 1 stop bit. After each command is executed, the associated response from the R5000 will be issued followed by a prompt character. For systems where the console port is being commanded by software, the software should wait for this prompt character before sending each and every command to the R5000.

It is possible to switch one or all of the switch ports to the A or B connection state using the appropriate serial commands. It is also possible to query the position of any one of the switch ports in a particular rack using serial commands. The RS232 serial interface is NOT affected by the position of the front panel keylock switch – it will act upon and respond to commands it receives even if the keylock switch is in the DISABLE position.

The following commands are available from the RS232 console prompt of an SNMP/Ethernet version of Controller Card. All commands are case insensitive, although several variable parameters are case sensitive (read/write community names and web password). GET, SET, SYSTEM, RACK, PORT, and ALL can all be abbreviated by the first letter of the command, allowing shorthand entry of switching commands.

GET ALL

Displays all parameters and settings. An example output is shown here.

```
System Status: X
IP Address: 192.168.1.30
MAC Address: 00 06 57 00 01 02
Subnet Mask: 255.255.255.0
Gateway IP Address: 192.168.1.1
PING Reply: Enabled
SNMP Enable: Enabled
Read Community Name: public
Write Community Name: private
Web Enable: Enabled
Web Password: mctech
Web Timeout: 300
Web Port: 80
Telnet Enable: Enabled
Telnet Password: dataman
Telnet Timeout: 80
Telnet Port: 23
Monitor IP Address: 0.0.0.0
Monitor MAC Address: 00 00 00 00 00 00
Monitor Interval: 10
Monitor Fail Count: 5
Monitor OK Count: 5
Authentication Trap: Disabled
Alert Type: TRAP
Model 1: 2.9T APR 2014, Rev. 50.CK
ADMIN IP Addresses:
SNMP Managers:
1: 192.168.1.113
2: 192.168.1.115
```

GET VERSION

Displays the software revision of the Ethernet module and Controller Card.

```
Model 1: 2.9T APR 2014, Rev. 50.CK
```

Market Central, Inc.

GET SYSTEM

This command is not supported in the R5000. If this command is issued to the R5000 it will respond with the following:

```
System Status: X
```

SET SYSTEM A[B]

Sets all of the A/B Switch Cards in the entire system (all connected racks) to position A or B.

GET RACK N

This command is not supported in the R5000. If this command is issued to the R5000 it will respond with the following:

```
Rack Status: XXXXXXXXXXXXXXXXXXXX
```

SET RACK N A[B]

Sets all of the A/B Switch Cards in the addressed rack N (1-255) to position A or B.

GET PORT N

Displays the status of switch card N (1-255). The response will be "Port Status: A", "Port Status: B", or "Port Status: no response" if there isn't a switch card present at address "N".

SET PORT N A[B]

Sets the addressed card N (1-255) to position A or B.

GET POWER N

Displays the status of the power supplies for rack N. If only one power supply is being used to power the rack or if one of the supplies in a dual powered rack is down, the response will be "Power Status: One Supply Down". If two supplies are used and both are operational, the response will be "Power Status: Two Supplies".

SET IPADDRESS X.X.X.X

GET IPADDRESS

Set or display the current IP address of the Ethernet module. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET SUBNETMASK X.X.X.X

GET SUBNETMASK

Set or display the current subnet mask of the Ethernet module. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET GATEWAY X.X.X.X

GET GATEWAY

Set or display the gateway router's IP address. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET PINGREPLY ON[OFF]

GET PINGREPLY

Set or display whether or not the Ethernet interface will respond to incoming PINGs (ICMP echo requests). Any change will not become permanent until a SAVE operation is performed.

SET SNMPENABLE ON[OFF]

GET SNMPENABLE

Set or display whether or not the SNMP interface is enabled. Any change will not become permanent until a SAVE operation is performed.

Market Central, Inc.

SET READCOMMUNITYNAME string

GET READCOMMUNITYNAME

SET WRITECOMMUNITYNAME string

GET WRITECOMMUNITYNAME

Set or display the current read or write community name as specified. Note that in general these are case sensitive fields. The password must be at least 1 char and no more than 8 chars in length. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET WEBENABLE ON[OFF]

GET WEBENABLE

Set or display the current state of web based access. The Ethernet module will not accept any HTTP requests when web enable is off. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET WEBPASSWORD string

GET WEBPASSWORD

Set or display the current web password. Note that this is a case sensitive field. The password must be at least 1 char and no more than 8 chars in length. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET WEBTIMEOUT seconds

GET WEBTIMEOUT

Set or display the current web timeout in seconds. After a period of inactivity of this many seconds, the Ethernet module will request a login. Note that the web timeout cannot be disabled, it can however, be set arbitrarily large.

SET WEBPORT N

GET WEBPORT

Set or display the current web port number. Changing the web port number from the default can be used to provide an additional level of security. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET TELNETENABLE ON[OFF]

GET TELNETENABLE

Set or display the current state of telnet based access. The Ethernet module will not accept any telnet requests when telnet enable is off. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET TELNETPASSWORD string

GET TELNETPASSWORD

Set or display the current telnet password. Note that this is a case sensitive field. The password must be at least 1 char and no more than 8 chars in length. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET TELNETTIMEOUT seconds

GET TELNETTIMEOUT

Set or display the current telnet timeout in seconds. After a period of inactivity of this many seconds, the Ethernet module will disconnect any current telnet session. Note that the telnet timeout cannot be disabled, it can however, be set arbitrarily large.

SET TELNETPORT N

GET TELNETPORT

Set or display the current telnet port number. Changing the telnet port number from the default can be used to provide an additional level of security. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET MONITORIP [X.X.X.X]

GET MONITORIP

Set or display the IP address of the device that the Ethernet module is to PING when using the auto switching feature. Setting this to 0.0.0.0 disables the auto switch/recovery function. Any change will not become permanent until a SAVE operation is performed. If enabled, the auto switch/recovery functions will PING the monitor IP

Market Central, Inc.

address. When the PING is not successful, the Switching System will auto-failover to the alternate path (A), connecting all C ports to their respective A ports. When the PING is successful, the Switching System will auto-recover to the normal path (B), connecting all C ports to their respective B ports.

SET MONITORMAC [X X X X X X]

GET MONITORMAC

Set or display the MAC (Ethernet) address of the device that the Ethernet module is to PING when using the auto switching feature. This value is entered as a series of six HEX characters with spaces between each HEX character. If monitoring connectivity to a device on the same subnet as the internal Ethernet module, set the monitormac address parameter to the MAC address of the device being monitored. If monitoring connectivity to a device on a different subnet/network than the internal Ethernet module, set the monitormac address parameter to the MAC address of the gateway router on the Ethernet module subnet. If the monitormac address is set to 00 00 00 00 00 00, the Ethernet module will automatically determine the proper MAC address required for the PING packet by issuing an ARP request to the gateway router. Any change will not become permanent until a SAVE operation is performed.

SET MONITORINTERVAL [N]

GET MONITORINTERVAL

Set or display the time interval between PINGs issued by the internal Ethernet module, measured in 100 msec increments. To issue PINGs every 1.5 seconds, set this value to 15. The valid range is 1 to 255 (0.1 seconds to 25.5 seconds). A value of 0 disables the automatic switch/recovery function. Any change will not become permanent until a SAVE operation is performed.

SET MONITORFAILCOUNT [N]

GET MONITORFAILCOUNT

Set or display the number of successive PING attempts that must fail before the Switching System automatically switches (fails over) to the alternate paths and removes the normal path connection paths. The valid range is 1 to 255. A value of 0 disables the automatic switch/recovery function. Any change will not become permanent until a SAVE operation is performed.

SET MONITOROKCOUNT [N]

GET MONITOROKCOUNT

Set or display the number of successive PING attempts that must succeed before the Switching System automatically switches back (recovers) to the normal paths and removes the alternate connection paths. The valid range is 1 to 255. A value of 0 disables only the automatic recovery function – automatic switching will still operate if enabled. If auto recovery is disabled the user must manually switch back to the normal path via the front panel toggle switch or by issuing a “SET SYSTEM B” command. Any change will not become permanent until a SAVE operation is performed.

SET AUTHENTICATIONTRAP ON[OFF]

GET AUTHENTICATIONTRAP

Set or display the current state of authentication error traps. Authentication traps will be generated when this parameter is set to ON, and not when OFF. Note that this setting only affects the trap generation, and not how the Ethernet module handles an authentication failure. An authentication failure generally means that an SNMP access was attempted with an incorrect community name. Any change will not become permanent until a SAVE and RESET operation sequence is performed.

SET ALERTTYPE [TRAP/SYSLOG]

GET ALERTTYPE

Set or display the type of alert messages sent by the internal Ethernet module when certain events such as a change in switch state occur. The Ethernet module can be configured to issue either syslog messages, or SNMP traps. Note that at least one IP address must be entered using the “SET MANAGER N X.X.X.X” command before either syslog messages or traps will be issued. See section 9 for a list of the traps supported by the Switching System, and see section 10 for a list of the supported syslog messages.

SET ADMINIP N X.X.X.X

Set administrator N (1-8) IP address. Up to 8 different administrator IP addresses can be entered. To remove an entry from the list, set the IP address to 0.0.0.0. If all 8 ADMIN IP addresses are 0.0.0.0 (no ADMIN IP addresses are configured) the internal Ethernet module will allow access from any IP address, subject to the existing password and enable flags for each interface. If one or more ADMIN IP addresses are non-zero, the internal Ethernet module will only process messages received from the configured (non-zero) ADMIN IP addresses. All other messages will

Market Central, Inc.

be ignored. This ADMIN IP address filtering feature applies to the telnet, web browser and SNMP Ethernet interfaces and to the PING reply functions. The ADMIN IP address filtering does not affect outgoing PING and ARP messages so the Ethernet module is still able to monitor any IP address for the “auto-switch” features. The administrator IP addresses can be different than the manager IP addresses. Any change will not become permanent until a SAVE operation is performed.

GET ADMINIP N

Display the IP address of administrator N (1-8). If no value is entered for “N”, then all administrator IP addresses will be displayed.

```
ADMIN IP Addresses:
1: 192.168.1.113
2: 192.168.1.115
```

SET MANAGER N X.X.X.X

Set SNMP manager N (1-16) IP address. Up to 16 SNMP MANAGER IP addresses can be entered for destinations of trap messages. Trap messages will be sent to all enabled MANAGER IP addresses. To remove an entry from the list, set the IP address to 0.0.0.0.

```
SNMP Managers:
1: 192.168.1.113
2: 192.168.1.115
```

GET MANAGER N

Display SNMP manager N (1-16) IP address.

GET MANAGER

Display all SNMP manager IP addresses.

PING X.X.X.X

The internal Ethernet module issues a single ICMP echo request packet to the designated IP address. If a response is received, the Ethernet module will display the message “Reply from X.X.X.X”. If no response is received within 5 seconds, the Ethernet module will display the message “Request timed out”.

SAVE

Save settings for next startup. All settings are stored in NV memory and restored upon power on. Any changes will not become permanent until a SAVE and RESET operation sequence is performed.

RESET

Causes the internal Ethernet module to reboot and reloads all parameters from stored settings. The Ethernet module takes about 10 seconds to reboot completely.

SET DEFAULTS

Restore user default settings. A SAVE operation is required to make the changes permanent.

?

HELP

Displays a list of commands.

```
CONSOLE COMMANDS:
GET          ALL (display all parameters)
GET          VERSION (display software versions)
GET[SET]    SYSTEM [A/B] (control all system ports)
GET[SET]    RACK N [A/B] (control single rack ports)
GET[SET]    PORT N [A/B] (control single port)
GET         POWER N (display power status)
GET[SET]    IPADDRESS [X.X.X.X]
GET[SET]    SUBNETMASK [X.X.X.X]
GET[SET]    GATEWAY [X.X.X.X]
GET[SET]    PINGREPLY [ON/OFF]
GET[SET]    SNMPENABLE [ON/OFF]
GET[SET]    READCOMMUNITYNAME [string]
GET[SET]    WRITECOMMUNITYNAME [string]
```

Market Central, Inc.

```
GET[SET]    WEBENABLE [ON/OFF]
GET[SET]    WEBPASSWORD [string]
GET[SET]    WEBTIMEOUT [N] (seconds)
GET[SET]    WEBPORT [N]
GET[SET]    TELNETENABLE [ON/OFF]
GET[SET]    TELNETPASSWORD [string]
GET[SET]    TELNETTIMEOUT [N] (seconds)
GET[SET]    TELNETPORT [N]
GET[SET]    MONITORIP [X.X.X.X] (0.0.0.0 to disable)
GET[SET]    MONITORMAC [X X X X X X] (X = HEX CHARS)
GET[SET]    MONITORINTERVAL [N] (1/10 seconds, 0 to disable)
GET[SET]    MONITORFAILCOUNT [N] (0 to disable)
GET[SET]    MONITOROKCOUNT [N] (0 = no auto recover)
GET[SET]    AUTHENTICATIONTRAP [ON/OFF]
GET[SET]    ALERTTYPE [TRAP/SYSLOG]
GET[SET]    ADMINIP N [X.X.X.X] (0.0.0.0 to disable an entry)
GET         ADMINIP (display all administrator IP addresses)
GET[SET]    MANAGER N [X.X.X.X] (0.0.0.0 to disable an entry)
GET         MANAGER (display all SNMP managers)
PING        X.X.X.X (ICMP ECHO to remote host)
SAVE        save settings for next startup
RESET       restart (use after SAVE)
SET         DEFAULTS (restore default user settings, save required)
```

Notes:

- Commands can be entered in upper or lower case. Passwords are case sensitive.
- All commands must be terminated with a carriage return (ASCII 13) or (hex 0x0D).

8. Web Interface (SNMP/Ethernet version of Controller Card)

The Ethernet module on the SNMP/Ethernet version of Controller Card also allows access to the enhanced console commands listed in section 7 through either a telnet connection or a web browser interface. When enabled (see SET WEBENABLE command) accessing the default page by typing the Controller Card's IP address in the address bar of your web browser will present the following page:

Web Interface Version 1.0
Copyright (c) 2014.
All rights reserved.

Please logon:

Password:

Figure 8.1 Logon Screen

Note: If using a pop up blocker on your web browser, be sure to allow pop ups from the IP address of the internal Ethernet module, otherwise you could experience trouble receiving a response through the web interface.

After successfully entering the correct web password (see SET WEBPASSWORD command) you will get the command console page shown in Figure 8.2.

IMPORTANT: Do **NOT** click on the “submit” button or press the “enter” key on your keyboard multiple times. The web browser interface on the Ethernet module typically responds within a few seconds but may take as long as 5 to 10 seconds to process certain commands and return a response. Clicking on “submit” or hitting “enter” multiple times while the Ethernet module is processing a command can cause it to decide that the interface is not functioning properly. If this happens, the Ethernet module will become non-responsive until it receives a valid login request i.e. you must re-enter the Ethernet module's IP address in the address bar of your web browser, and then re-logon when the logon screen appears.

Market Central, Inc.

Web Interface Version 1.0
Copyright (c) 2014.
All rights reserved.

Command console:

Enter new command:

Figure 8.2 Initial Command Screen

At this point you may enter any valid console command listed in section 7 into the text box and click “Send Command” to execute. The following is an example result of the GET PORT 1 command.

Web Interface Version 1.0
Copyright (c) 2014.
All rights reserved.

Command console:

Output from last command...

Port Status: A

Enter new command:

Figure 8.3 Example Command Results Screen for GET PORT 1 command

The internal Ethernet module will allow only 1 telnet or web access session at a time. For this reason, the web timeout and telnet timeout parameters should be set to reasonable timeout values. To free up a session without waiting for the web timeout, click “Logoff”. Typing “quit” at the telnet prompt will similarly close a telnet session. Resetting the Ethernet module will also clear any existing web or telnet sessions.

Market Central, Inc.

9. SNMP MIB Path Summary

NOTE: The MIB contains definitions that do not apply to every product in the R5000 family.

[internet] – 1.3.6.1

 [private] – 1.3.6.1.4

 [enterprises] – 1.3.6.1.4.1

 [mctech] – 1.3.6.1.4.1.9477

[mctech] – 1.3.6.1.4.1.9477

 Market Central, Inc. private enterprise number

[mcAgent] – 1.3.6.1.4.1.9477.1

 Market Central, Inc. SNMP Agent

[abSwitchSystem] – 1.3.6.1.4.1.9477.1.4

 A/B Switch System

 [abSystemGangPort] – 1.3.6.1.4.1.9477.1.4.1

 [abRackTable] – 1.3.6.1.4.1.9477.1.4.2

 [abRackIndex] – 1.3.6.1.4.1.9477.1.4.2.1.1.RackIndex

 [abRackGangPort] – 1.3.6.1.4.1.9477.1.4.2.1.2.RackIndex

 [abRackKeyStat] – 1.3.6.1.4.1.9477.1.4.2.1.3.RackIndex

 [abRackPowerStat] – 1.3.6.1.4.1.9477.1.4.2.1.4.RackIndex

 [abRackSoftwareVersion] – 1.3.6.1.4.1.9477.1.4.2.1.5.RackIndex

 [abRackName] – 1.3.6.1.4.1.9477.1.4.2.1.6.RackIndex

 [abRackCards] – 1.3.6.1.4.1.9477.1.4.2.1.7.RackIndex

 [abSwitchTable] – 1.3.6.1.4.1.9477.1.4.3

 [abSwitchIndex] – 1.3.6.1.4.1.9477.1.4.3.1.1.SwitchIndex

 [abSwitchPort] – 1.3.6.1.4.1.9477.1.4.3.1.2.SwitchIndex

 [abSwitchSoftwareVersion] – 1.3.6.1.4.1.9477.1.4.3.1.3.SwitchIndex

 [abSwitchName] – 1.3.6.1.4.1.9477.1.4.3.1.4.SwitchIndex

[mclpRequester] – 1.3.6.1.4.1.9477.2

[mcTrapInfo] – 1.3.6.1.4.1.9477.3

 [mcGenericTrap] – 1.3.6.1.4.1.9477.3.1

 [mcSpecificTrap] – 1.3.6.1.4.1.9477.3.2

[mcManagerTable] – 1.3.6.1.4.1.9477.4

 [mcManagerIndex] – 1.3.6.1.4.1.9477.4.1.1.ManagerIndex

 [mcManagerIrp] – 1.3.6.1.4.1.9477.4.1.2.ManagerIndex

Traps generated by the system

| | |
|--------------------------|-----------------|
| coldStart | generic trap 0 |
| authenticationFailure | generic trap 4 |
| abRackKeyLockChange | specific trap 1 |
| abRackGangSwitchChange | specific trap 2 |
| abSystemGangSwitchChange | specific trap 6 |
| abRackPowerStatChange | specific trap 7 |
| abSystemAutoSwitchChange | specific trap 8 |

Market Central, Inc.

A/B Switch System SNMP Variable Definitions:

[abSystemGangPort] – 1.3.6.1.4.1.9477.1.4.1

A/B Switch System gang port. This variable is used to control all A/B Switch Cards in the system. A system may consist of up to 255 racks, each rack containing up to 16 A/B Switch Cards. It is write only.

[abRackTable] – 1.3.6.1.4.1.9477.1.4.2

A/B Switch Rack variable table. This variable is not directly accessible.

[abRackIndex] – 1.3.6.1.4.1.9477.1.4.2.1.1.RackIndex

A/B Switch Controller “Rack” address. The A/B Switch Controller address is set via an eight position dip switch on the card. Each A/B Switch Controller in the system MUST have a unique address, in the range of 0x01 to 0xFF hex. Address 0x00 is invalid, and must not be used. This is a read only variable.

[abRackGangPort] – 1.3.6.1.4.1.9477.1.4.2.1.2.RackIndex

A/B Switch Rack gang port. This variable is used to control all A/B Switch Cards in a rack. A rack may contain up to 16 A/B Switch Cards. It is write only.

[abRackKeyStat] – 1.3.6.1.4.1.9477.1.4.2.1.3.RackIndex

A/B Switch Rack Key-Lock Switch Status. This is a read only variable. This variable can be used to determine if the Key-Lock Switch is in the OFF or ON position. The front panel switches in the rack are disabled when the Key-Lock Switch is in the OFF position. The A/B Switches will still respond to switch control signals and commands from the GANG-IN and GANG-OUT ports.

[abRackPowerStat] – 1.3.6.1.4.1.9477.1.4.2.1.4.RackIndex

A/B Switch Rack Power Status. This is a read only variable.

The 2U A/B Switch controller rack may contain one or two power supplies. If one power supply is installed and operating, the Power Status will report “OneSupply”. If two power supplies are installed and both are operating, the Power Status will report “TwoSupplies”. If two power supplies are installed and one is off line, the Power Status will report “One Supply Down”.

[abRackSoftwareVersion] – 1.3.6.1.4.1.9477.1.4.2.1.5.RackIndex

A/B Switch Controller Software Version. This is a read only variable, and is limited to a maximum of 14 characters.

[abRackName] – 1.3.6.1.4.1.9477.1.4.2.1.6.RackIndex

A/B Switch Controller Identification String. The string is limited to a maximum of 14 characters.

[abRackCards] – 1.3.6.1.4.1.9477.1.4.2.1.7.RackIndex

A/B Switch Rack Card Status, One character for each of the sixteen cards in the rack. This variable is present for compatibility with other A/B switching systems. It is read only and will respond “NA”.

[abSwitchTable] – 1.3.6.1.4.1.9477.1.4.3

A/B Switch Rack variable table. This variable is not directly accessible.

[abSwitchIndex] – 1.3.6.1.4.1.9477.1.4.3.1.1.SwitchIndex

A/B Switch “Card” address.

On a 2U A/B Switch System, the switch card address is set via an eight position dip switch on the card. Each 2U A/B Switch cards in the system MUST have a unique address, in the range of 0x01 to 0xFF hex. Address 0x00 is invalid, and must not be used. This is a read only variable.

Market Central, Inc.

[abSwitchPort] – 1.3.6.1.4.1.9477.1.4.3.1.2.SwitchIndex

A/B Switch Card port. This variable is used to control the A/B Switch Card selected port. When set to A, the switch will connect port A to port C. When set to B, the switch will connect port B to port C. If the addressed A/B Switch Card is not present, you will not get a response.

[abSwitchSoftwareVersion] – 1.3.6.1.4.1.9477.1.4.3.1.3.SwitchIndex

A/B Switch Card Software Version. This is a read only variable, and is limited to a maximum of 14 characters. On a 2U A/B Switch System, the A/B Switch cards have software. Therefore, this variable may be different, depending on the software version on each card.

[abSwitchName] – 1.3.6.1.4.1.9477.1.4.3.1.4.SwitchIndex

A/B Switch Card Identification String. The string is limited to a maximum of 14 characters.

[mcIpRequester] – 1.3.6.1.4.1.9477.2

The IP address of the remote entity that last accessed branch 1.3.6.1.4.1.9477.1. This variable can be used to identify the last IP address to access any mcAgent variable. It is returned in the authenticationFailure message.

[mpTrapInfo] – 1.3.6.1.4.1.9477.3

Group of trap information variables. This variable is not directly accessible.

[mcGenericTrap] – 1.3.6.1.4.1.9477.3.1

Indication of generic trap events. This variable is bit mapped such that bit 0 is trap 0, bit 1 is trap 1, etc. Write an integer with 1 in bit positions to clear particular trap indications. For example write 17 to clear traps 0 & 4.

[mcSpecificTrap] – 1.3.6.1.4.1.9477.3.2

Indication of specific trap events. This variable is bit mapped such that bit 1 is trap 1, bit 2 is trap 2, etc. Write an integer with 1 in bit positions to clear particular trap indications. For example write 18 to clear traps 1 & 4.

[mcManagerTable] – 1.3.6.1.4.1.9477.4

Table for SNMP Manager IP addresses. This variable is not directly accessible.

[mcManagerIndex] – 1.3.6.1.4.1.9477.4.1.1.ManagerIndex

Index used to identify unique entries in the Manager IP address table.

[mcManagerIp] – 1.3.6.1.4.1.9477.4.1.2.ManagerIndex

SNMP Manager IP address. Destination IP address for TRAP or SYSLOG messages.

A/B Switch System SNMP trap definitions:

All traps carry the sysObjectId (1.3.6.1.2.1.1.2) variable, whose value is 1.3.6.1.4.1.9477.1.

Coldstart – generic trap 0

This trap is sent during a power on initialization and reboot of the SNMP controller. It carries the sysDescr variable (1.3.6.1.2.1.1.1).

AuthenticationFailure – generic trap 4

This trap is sent as a result of an authentication failure in processing an SNMP request. Generally an authentication failure occurs as a result of an SNMP request with an invalid community name. It carries the IpRequester variable.

Market Central, Inc.

abRackKeyLockChange – specific trap 1

This trap is sent when the key switch is changed on a rack. It carries the abRackKeyStat variable.

abRackGangSwitchChange – specific trap 2

This trap is sent when a rack gang switch occurs. It carries the abRackGangPort variable.

abSystemGangSwitchChange – specific trap 6

This trap is sent when a system gang switch occurs. It carries the abSystemGangPort variable.

abRackPowerStatChange – specific trap 7

This trap is sent when the rack power supply status changes. It carries the abRackPowerStat variable.

abSystemAutoSwitchChange – specific trap 8

This trap is sent when a system auto switch occurs. It carries the abSystemGangPort variable.

10. Syslog Messages

The internal Ethernet module can be configured to issue a syslog message rather than an SNMP trap when certain events occur. To configure the Ethernet module to issue syslog messages, you must use the “SET ALERTTYPE” command to select SYSLOG messages, and you need to specify the IP address(es) of the device(s) that will be receiving the syslog messages by using the “SET MANAGER N X.X.X.X” command (see section 7 for details regarding these commands). Once these configuration parameters have been set, the Ethernet module will issue syslog messages for the following types of events:

- power up cold start, or restart using the RESET command
- SNMP authentication failure (access attempted using incorrect read or write community name)
- change in the state of the front panel keylock switch
- change in the state of the A/B switch ports in the rack caused by a user initiated “rack” command or the front panel toggle switch
- change in the state of the A/B switch ports in the rack caused by a user initiated “system” command or the front panel toggle switch
- change in the power ON/OFF state of either power input
- change in the state of the A/B switch ports due to the auto bypass or auto recovery switch functions

The syslog messages issued by the Ethernet module conform where possible to the general recommendations as described in RFC 3164. The Ethernet module does not have a real-time clock however, so each syslog message uses a default timestamp value of Jan 1 00:00:00. The device receiving the syslog messages will need to apply a timestamp or other identifier if this information is needed. The general format for each syslog message from the Ethernet module is as follows:

Jan 1 00:00:00 [Ethernet module IP address] Bypass Switch: [specific message based on the event that occurred]

Listed below is each type of syslog message that the Ethernet module can issue, followed by the actual syslog message that the Ethernet module will send.

power up cold start (or RESET command)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Switch has been reset.

SNMP authentication failure

Jan 1 00:00:00 192.168.1.151 Bypass Switch: SNMP authentication failure.

keylock switch change disabled to enabled

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Keyswitch change to ON position.

Market Central, Inc.

keylock switch change enabled to disabled

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Keyswitch change to OFF position.

system gang switch A to B via S S B command (or toggle switch)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: System switch to B position.

system gang switch B to A via S S A command (or toggle switch)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: System switch to A position.

rack gang switch A to B via S R 1 B command

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Rack switch to B position.

rack gang switch B to A via S R 1 A command

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Rack switch to A position.

applied power to PS1 (PS2 already powered up)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Power supply status changed to two supplies.

removed power from PS1 (PS2 still powered up)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Power supply status changed to one supply down.

removed power from PS2 (PS1 still powered up)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Power supply status changed to one supply down.

applied power to PS2 (PS1 already powered up)

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Power supply status changed to two supplies.

auto switch B to A via auto bypass feature

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Automatic switch to A position.

auto switch A to B via auto recovery feature

Jan 1 00:00:00 192.168.1.151 Bypass Switch: Automatic switch to B position.

Market Central, Inc.

WARRANTY LIMITATION OF REMEDIES AND LIABILITY

WARRANTY Market Central warrants to the original purchaser only that the products which are the subject of this Contract will be free of defects in workmanship and materials, under normal service and use, for a period of one (1) year from date of sale. Products which have been changed or altered in any manner from their original design, or which are improperly or defectively installed, tested, serviced or used, are not covered by this warranty. If any alleged failure to conform to this warranty shall arise during a period of one (1) year from date of sale, Market Central shall, upon prompt, written notice and compliance by Customer with such instructions as Market Central shall provide with respect to the return of allegedly defective products or parts, correct such non-conformity by repair or replacement, or by the refund of the purchase price or applicable portion thereof, at Market Central's sole discretion. Correction in the foregoing manner shall constitute a complete fulfillment of all obligations and liabilities of Market Central with respect to said products. THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; AND MARKET CENTRAL EXPRESSLY DISCLAIMS ANY SUCH WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

LIMITATION OF REMEDY. If any claim shall arise with respect to any alleged non-conforming product, Market Central's sole obligation and Customer's sole and exclusive remedy shall be the repair or replacement of said allegedly defective product or component or the refund of the applicable portion of the purchase price, at Market Central's sole discretion and at no cost to Customer, in accordance with the warranty provisions of the preceding paragraph. SAID REMEDY SHALL BE CUSTOMER'S SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO ANY ALLEGED NON-CONFORMING PRODUCT OR OTHER CLAIM AS TO THE CONDITION OF ANY PRODUCT OR COMPONENT, WHETHER IN THE NATURE OF A CLAIM FOR BREACH OF WARRANTY, NEGLIGENCE, TORT, STRICT LIABILITY, PRODUCT LIABILITY WITH RESPECT TO DESIGN AND/OR MANUFACTURE, OR OTHERWISE.

LIMITATIONS OF LIABILITY. In no event will Market Central be liable for any incidental, consequential, special or indirect losses or damages arising out of or in connection with the Contract, its performance or breach thereof, including without limitation any and all losses and damages arising out of or related to costs of removal and reinstallation of any item, loss of goodwill, loss of profits, delay and loss of use. MARKET CENTRAL'S LIABILITY WITH RESPECT TO ANY CLAIM OF ANY KIND FOR ANY LOSS OR DAMAGE SHALL NOT IN ANY EVENT EXCEED THE PRICE ALLOCABLE TO THE PRODUCT OR UNIT THEREOF WHICH GIVES RISE TO THE CLAIM; AND MARKET CENTRAL SHALL NOT BE LIABLE FOR ANY PENALTIES, PUNITIVE DAMAGES OR EXEMPLARY DAMAGES OF ANY KIND OR DESCRIPTION.

Federal Communications Commission (FCC) Statement

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Market Central® is a registered trademark of Market Central, Inc. All rights reserved.

Copyright © 2015. Market Central, Inc. All rights Reserved.